

Some dealers who are doing PIANOCORDER installations have developed ways of cutting down the time spent on piano keybed alteration. One of the most popular is described herein. A by product is that the end result is a precise and professional looking cut. 3/4" holes are drilled as described in our installation manual. But instead of a sabre saw, the slot(s) are cut by first using a heavy duty circular saw with a seven and one-fourth inch carbide blade then finishing with a hand saw or sabre saw in the small area not cut by the circular saw blade. Modification of the saw itself may be required to allow use in the confined space of the piano, particularly when used on upright pianos. NOTE: Extreme care must be used when operating this type of equipment.